

METEOR DETECTION OPERATING PROCEDURE

1. Turn on the FM car radios, tuning to 98.7 MHz.
2. Ensure that the white dots on the volume and balance controls are aligned with the white dot on the radio case.
3. In the Equipment Bay, run a patch cord from the 'FM Radio 'A' R Chan Out' jack and 'FM Radio 'B' R Chan Out' jack to either the 'Terra PC Line In' jack or 'SONof SOL Line In' jack, depending on which computer you're going to be using. Use a wye patch cord. Refer to the Patch Panel Configuration sheet for plug locations.
4. Start up the computer and double click on the Desktop shortcut 'SkyPipe' and run the program. Refer to the Radio-SkyPipe Server Mode procedure for details.