

## **0.61m Telescope Mirror Air Circulating Fan Procedure**

1. Turn on the lower power bar on the right side of the telescope base.
2. Turn on the left hand switch located on the telescope base power panel.
3. Turn on the fan control switch labeled 'FAN' located in the left rear quadrant on the back of the 24" telescope box.