

## **LASER POINTER OPERATING PROCEDURE**

1. Energize the AC receptacles on the piers by turning on breakers 5 and 7 in the right hand breaker panel located behind the bifold doors in the hallway leading to the dome.
2. Mount the laser pointer and white coroplast sheet on the northwest pier.
3. Plug the laser pointer in, turn it on, and test it.
4. To increase the friction for vertical pointer movement, turn the white knob on the vertical laser tube support.
5. Follow all safety procedures as outlined in the RASC Green Laser Policy located on the main hallway bulletin board and on the Centre website (Members Area/RASC Prince George Centre Green Laser Policy)
6. Do not allow unauthorized personnel to operate the laser pointer.
7. Dissuade people from inserting objects into the laser beam.
8. Turn the laser pointer off when it is unattended. Unplug it if necessary.