

ST-10XME CCD CAMERA ACTIVATION

1. Turn on the lower power bar located at the base of the main telescope.
2. Turn on the ST-10XME power supply attached to one of the telescope trusses.
3. The green light on the ST-10XME power supply should now be illuminated.