

## WIRELESS HAND PAD OPERATION

The wireless hand pad is stored in the control room.

1. Ensure the wireless hand pad cable is plugged into the servo controller hand pad port.
2. To turn the hand pad on, press the 'SPD' key. The 'Slew Mode' lamp on the hand pad receiver should illuminate.
3. To toggle between SLEW, PAN, and GUIDE modes, press the 'SPD' key.
4. Move the scope by using the arrow keys.
5. Turn tracking on and off by pressing the 'RTN' key.
6. The hand pad will turn off automatically after 15 minutes of activity. Press the 'SPD' key to turn the unit back on.
7. To turn the hand pad off, hold down the 'ALT' key and press the 'SPD' key.
8. Return the wireless hand pad to the control room when you are finished using it.

Additional instructions are located under 'Wireless Radio Handpad User Instruction Manual (Full)' in the Operating Instructions Binder and on the website. <http://pgrasc.org/members/members-area/observatory-operating-procedures/>