


FLIP MIRROR OPERATING PROCEDURE

1. Rotate the knurled knob 'A' located on the top of the flip mirror assembly counterclockwise until it clears its recess.
2. Rotate the mirror to the desired configuration. Avoid touching the mirror surface.
3. Rotate the knurled knob 'A' located on the top of the flip mirror assembly clockwise until it is seated snugly into its recess. **DO NOT OVERTIGHTEN.**



'A'