CLASSROOM CEILING PROJECTORS

Classroom Computer Projector

To Use:
- Turn on the west wall switch labelled Projector. This switch also turns on the outside north wall building sign.
- Turn on projector using the Benq projector's remote controller.

After Use:
- Turn off projector using the projector's remote controller.
- Turn off the wall switch after the projector has cooled off and switched off.

Telescope Mallincam Camera Projector

To use:
- Turn on the west wall switch labelled Projector. This switch also turns on the outside north wall building sign.
- Turn on projector using the Epson projector's remote controller.

After Use:
- Turn off projector using the projector's remote controller.
- Turn off the wall switch after the projector has cooled off and switched off.