

LOWER SHUTTER OPERATION

- Open the upper shutter.
- Activate the motor control hand pad to open the lower shutter.



- There are no limit switches in operation yet, so watch the door. 10 - 15 seconds should be enough time for the door to open sufficiently.
- Activate the motor control hand pad to close the lower shutter.
- The V belt will slip in the pulley when the door is closed.

Manual Operation

To open or close the lower shutter manually:

- Hold onto the crank handle and move it a bit to disengage the motor clutch by pulling out the motor knob and turning it 90°. **DO NOT LET GO OF THE CRANK HANDLE.** The manual brake has been removed.
- Crank the handle until the lower shutter is in the desired location.
- Still holding on to the crank handle, re-engage the motor clutch by turning the motor knob 90° and letting it pop back into position. You may need to wiggle the hand crank a bit.

