

ST-10XME CCD CAMERA ACTIVATION

1. Activate the IP9258 1-2 selection.
2. Turn on the ST-10XME power supply attached to one of the telescope trusses.
3. The green light on the ST-10XME power supply should now be illuminated.