

DIGITAL CAMERA - VIVITAR V3350

- 1) The digital camera is located on the table beside the classroom computer (Terra)
- 2) Before and after use, please remove the batteries from the camera. It takes two AAA batteries. This is to prevent damage to the camera and to keep the batteries from discharging when stored without use for long periods.
- 3) Before using the camera, please familiarize yourself with its operation via the [User Manual](#).
- 4) The USB cable necessary to download the images to the computer is attached to the classroom computer (Terra) and is draped so that it is on top of the tower.
- 5) After acquiring images you should download them as soon as possible into the computer.
- 6) The software for downloading the images has an icon on the desktop called V3350. It looks like a small image of the camera. Plug the camera into the USB cable and double click the icon. Follow the on screen instructions to download the images.
- 7) For photo manipulation there is also basic photo editing software package installed on the computer called Photoimpression. It also has an icon of the desktop.