

MALLINCAM STARTUP/SHUTDOWN PROCEDURE

1. Turn on the white power bar at the base of the main telescope.
2. Double click the Mallincam Camera icon on the desktop.
3. On the Advanced tab, the camera will count down from 3 minutes.
4. For operating procedures, consult the information in the Mallincam binder located on the observing deck and/or the Mallincam Help icon on the desktop.
5. After the camera has completed its countdown, click Video/Device and select the USB 2828x video device to show the video control settings and allow images to be previewed.
6. When finished with the camera, click Park on the Config tab. The camera will count down from 3 minutes. **DO NOT TURN THE CAMERA POWER OFF UNTIL A WINDOW APPEARS STATING IT IS SAFE TO POWER OFF THE CAMERA.**
7. Turn off the white power bar.

For assistance with operation of the camera:

Mike Matwyuk 250 964-6285

Glen Harris 250 562-4488